

Riffraff Diesel HPOP JIC Hose 1999-2003 7.3L



INSTALLATION INSTRUCTIONS



IMPORTANT: Before starting installation, please be sure that all items which were supplied with the kit are accounted for.

Disclaimer of Warranties and Liabilities: Riffraff Diesel disclaims any responsibility/liability for improper, incorrect, or inexperienced installation of products by the consumer or paid installer resulting in damage or loss. Buyer affirms by purchase of this product that it is fit for intended use and accepts all liability.

Buyer affirms products purchased are engineered to increase automotive performance and are used at buyer's own risk and accepts full responsibility.

INSTRUCTIONS

- 1 The factory HPOP hoses are fastened to the heads and the HPOP using special Eaton STC® quick disconnect fittings. These fittings allow the hoses to easily be removed using a special tool.
- 2 The driver side hose goes to the forward fitting on the HPOP and the passenger side hose goes to the aft fitting. (Note: Fuel bowl is removed in the pictures for clarity. It is not required to remove the fuel bowl to replace the hoses).
- 3 Clean the hose fittings thoroughly before disconnecting. This will reduce the likelihood that you will introduce contaminants into the high pressure oil system.
- 4 Insert the HPOP Line disconnect tool behind the release sleeve on the cylinder head fittings to disconnect the locking ring from the fittings. Pull the hoses free from the fittings. (fig. 1, fig. 2) (fig. 4, fig. 5) Insert the HPOP Line Disconnect tool behind the release sleeve on the HPOP fittings and pull the hoses free from the fittings. Remove the hoses from the engine. (fig. 3)
- 5 Remove the Quick Disconnect Fitting from the drivers and passenger heads. (fig. 4, fig. 5)

Parts Required:

1. (1) Driver Side Head:
Part# RDP-HPOP-DRVR
2. (1) Passenger Side Head:
Part# RDP-HPOP-PASS

Recommended Parts:

1. (1) Riffraff Diesel HPOP Line Disconnect
Tool: Part# 6595



fig. 1




fig. 2

fig. 3





fig. 4



fig. 5

- 6 Evacuate some of the oil in the head to eliminate oil dripping out. This will allow you to clean the threaded area for the Loctite to engage better.
- 7 Remove the fittings from the High Pressure Oil Pump. Heat will help the Loctite release the fitting. (**fig. 3, fig. 6**)
- 8 Remove the two check springs from the HPOP. These will not be utilized with the new installation. (**fig. 6, fig. 7**)
- 9 Install the fittings into each cylinder head and torque to 30 ft-lbs. The Passenger Side Head uses the 45° fitting and is pointed towards the Driver Side Head. Tighten the jam nut to hold it in place. (**fig. 9**)
- 10 Apply Loctite 680 to the boss threads (o-ring side) (**fig.8**) of the new JIC fittings and install into the HPOP and torque to 25 ft-lbs. Do not apply Loctite to the flared end threads.
- 11 Route the new JIC Hoses from the HPOP to each cylinder head fitting using the same path as the original hoses. The 90° fittings are the HPOP end fittings and the longer hose is for the passenger side head.
- 12 Start each hose end nut onto the fitting before final tightening of the hose fitting. Torque the fittings to 20 ft-lbs.
- 13 After installing the new lines the truck may start hard/slowly and run rough. This will get better after roughly 75 miles as there is air in the high pressure oil system. It will purge out while driving.
- 14 Let the engine idle for 5-10 minutes, check for leaks. After idling drive the truck and check for leaks.



Instructions and pictures provided by Ken (Woodnthings on FTE)